


# Simon XT User Manual



**Copyright** Copyright © 2007 GE Security. All rights reserved.

This document may not be copied in whole or in part or otherwise reproduced without prior written consent from GE Security except where specifically permitted under US and international copyright law.

Document number/ **466-2266B** (March 2007).

**Disclaimer** The information in this document is subject to change without notice. GE Security, Inc. ("GE Security") assumes no responsibility for inaccuracies or omissions and specifically disclaims any liabilities, losses, or risks, personal or otherwise, incurred as a consequence, directly or indirectly, of the use or application of any of the contents of this document. For the latest documentation, contact your local supplier or visit us online at [www.gesecurity.com](http://www.gesecurity.com).

This publication may contain examples of screen captures and reports used in daily operations. Examples may include fictitious names of individuals and companies. Any similarity to names and addresses of actual businesses or persons is entirely coincidental.

**Trademarks and patents** GE and the GE monogram are registered trademarks of General Electric Company. Simon X7 product and logo are registered trademarks of GE Security.

Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the respective products.

This product and the use of this product may be covered by one or more of the following patents: 5,805,063, 5,872,512, 5,942,981, 5,686,896, 5,686,885, 4,855,713. Except expressly provided herein, the purchase of this product shall not constitute a license or otherwise provide a right to practice a method covered by any of the identified patents. GE Security hereby grants the purchaser of this product a limited, nonexclusive license to practice the methods patented in the identified patents solely with products manufactured, sold or licensed by GE Security. This license grant does not extend to the use of unlicensed, third party products with this product.

**Software license agreement** **Important:** This end-user license agreement ("Agreement") is a legal agreement between GE SECURITY and You. Read the following terms and conditions carefully before installing or using this Software. This agreement provides a license from GE SECURITY to use the Software. It also contains warranty information, disclaimers, and liability limitations. Installing and/or using the Software confirms Your agreement to be bound by these terms and conditions. If You do not agree with these terms and conditions, do not install or use the Software or, if already installed, immediately cease all use of the Software and promptly uninstall all components of the Software.

**1. Definitions.** The following definitions apply to this document:

- a. "GE SECURITY", with respect to title to or warranty of the Software, means GE Security Inc., a Delaware corporation.
- b. "Software" means the executable software or firmware programs and accompanying documentation installed on the GE SECURITY products, plus any upgrades, modified versions, updates, additions, and copies of the software furnished to Customer during the term of the license granted herein.
- c. "Documentation" means all associated media, printed materials, and electronic documentation accompanying the Software.
- d. "Licensed Product" means the Software and Documentation.
- e. "Customer" means the person or organization, or parent or subsidiary thereof, who uses the Software for its intended purposes, and excludes distributors, authorized resellers, value-added resellers and original equipment manufacturers. Customer may be referred to as You or Your, whether an individual or a business entity of any kind.
- f. "Machine" means the computer, workstation, terminal, or other hardware product on which the Software is installed.

**2. License.** All rights to and in the Licensed Product, including, but not limited to, copyrights, patents, trademarks, and trade secrets, belong to GE SECURITY, and GE SECURITY retains title to each copy of the Software. You agree that GE SECURITY at any time, upon reasonable notice, may audit Your use of the Software for compliance with the terms and conditions of this Agreement. Subject to the terms and conditions of this Agreement, GE SECURITY grants You a nonexclusive license to use the Software, but only in the country where acquired, provided that You agree to the following:

You may:

- a. install and use the Software on a single Machine at one time, unless You have purchased additional copies of the Software, in which case You may install the software on the number of Machines for which You have purchased copies of the Software;
- b. use the original copy of the Software provided to You for backup purposes.

You may not:

- a. transfer or distribute the Licensed Product to others, in electronic format or otherwise, and this Agreement shall automatically terminate in the event of such a transfer or distribution;
- b. use the Software over a computer network;
- c. sell, rent, lease, or sublicense the Software;
- d. copy or modify the Licensed Product for any purpose, including for backup purposes.

**3. Term.** This Agreement is effective until terminated. You may terminate this Agreement by uninstalling all components of the Software from all Machines and returning the Software to GE SECURITY. GE SECURITY may terminate this Agreement if You breach any of these terms and conditions. Upon termination of this Agreement for any reason, You agree to uninstall all components of the Software and return the Licensed Product to GE SECURITY. All provisions of this Agreement relating to (i) disclaimer of warranties; (ii) limitations on liability, remedies, and damages; and (iii) GE SECURITY's proprietary rights, shall survive termination of this Agreement.

**4. Object code.** The Software is delivered in object code only. You may not alter, merge, modify, adapt, or translate the Software, nor decompile, disassemble, reverse-engineer, or otherwise reduce the Software to a human-perceivable form, nor create derivative works or programs based on the Software.

**5. Limited warranty.** GE SECURITY warrants that for one (1) year from the date of delivery of the Licensed Product (Software Warranty Period), the functions contained in the Software will be fit for their intended purpose as described in the applicable Documentation from GE SECURITY, and will conform in all material respects to the specifications stated in such Documentation. GE SECURITY does not warrant that the operation of the Software will be uninterrupted or error-free. GE SECURITY does warrant that the media on which the Software is furnished will be free from defects in materials and workmanship under normal use for a period of thirty (30) days from the date of delivery (Media Warranty Period). Except as specifically provided therein, any other software and any hardware furnished with or accompanying the Software is not warranted by GE SECURITY.

Your exclusive remedy under this limited warranty for nonconforming Software shall be repair or replacement of the Software, at the sole discretion of GE SECURITY. To obtain a repair or replacement of nonconforming Software, contact GE SECURITY Customer Service toll-free at 888-GESECURity or online at [www.gesecurity.com](http://www.gesecurity.com) during the Software Warranty Period.

Except as expressly provided above, the licensed product is provided "as is" without warranty of any kind, either expressed or implied, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose and, except as expressly provided above, You assume the entire risk as to the quality and performance of the licensed product.

**6. Limitation of liability.** GE SECURITY's sole obligation or liability under this agreement is the repair or replacement of nonconforming software and/or defective media according to the limited warranty above. In no event will GE SECURITY be liable for damages, whether consequential, incidental, or indirect, nor for loss of data, loss of profits, or lost savings, arising from use or inability to use the software or documentation (or any hardware furnished with the software), even if GE SECURITY has been advised of the possibility of such damages, nor for any claim by any third party.

**7. General.** Any materials provided to You by GE SECURITY shall not be exported or reexported in violation of any export provisions of the USA or any other applicable jurisdiction. Any attempt to sublicense, assign, or transfer any of the rights, duties, or obligations hereunder shall be void. This Agreement shall be governed by and interpreted under the laws of the State of New York, United States of America, without regard to conflicts of law provisions. You hereby consent to the exclusive jurisdiction of the state and federal courts located in Multnomah County, Oregon, to resolve any disputes arising under or in connection with this Agreement, with venue in Portland, Oregon.

**8. Restricted rights legend.** The Licensed Product is provided with RESTRICTED RIGHTS. In the event the United States Government or an agency thereof is granted a license, the following additional terms apply: Restricted Computer Software, as defined in the Commercial Computer Software–Restricted Rights clause at Federal Acquisition Regulations 52.227-19, and the restrictions as provided in subparagraphs (c)(1) and (c)(2) thereof; and as applicable, the Government's rights to use, modify, reproduce, release, perform, display, or disclose the Software also are restricted as provided by paragraphs (b)(2) and (b)(3) of the Rights in Noncommercial Technical Data and Computer Software–Small Business Innovative Research (SBIR) Program clause at DFARS 252.227-7018.

**9. Acknowledgment.** You acknowledge that You have read and understand this agreement and agree to be bound by its terms. You further agree that this agreement is the complete and exclusive statement of the agreement between You and GE SECURITY, and supersedes any proposal or prior agreement, oral or written, and any other communication relating to the subject matter of this agreement.

<b>Intended use</b>	Use this product only for the purpose it was designed for; refer to the data sheet and user documentation. For the latest product information, contact your local supplier or visit us online at <a href="http://www.gesecurity.com">www.gesecurity.com</a> .
<b>FCC compliance</b>	Changes or modifications not expressly approved by GE Security can void the user's authority to operate the equipment.

**FCC Part 15 Class B**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the affected equipment and the panel receiver to separate outlets, on different branch circuits.

Consult the dealer or an experienced radio/TV technician for help.

**ACTA Part 68**

This equipment complies with Part 68 of the FCC Rules. Located on this equipment is a label that contains, among other information, the FCC registration number and the ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

FCC Part 68 Registration No. US:B4ZAL02B55910

The REN is used to determine the maximum number of devices that may be connected to your telephone line. Excessive RENs on a telephone line may result in devices not ringing in response to an incoming call. In most areas, the sum of all device RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements as adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compliant modular jack that is also compliant. See the Installation Instructions for details.

Alarm dialing equipment must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already has the telephone line in use. To do so, alarm dialing equipment must be connected to a properly installed RJ31X jack that is electrically in series and ahead of all other equipment attached to the same telephone line. If you have any questions concerning these instructions, consult your local telephone company or a qualified installer about installing an RJ31X jack and alarm dialing equipment for you.

If this equipment causes harm to the telephone network, the telephone company may temporarily disconnect your service. If possible, you will be notified in advance. When advance notice is not practical, you will be notified as soon as possible. You will also be advised of your right to file a complaint with the FCC.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. You will be given advance notice in order to maintain uninterrupted service.

If you experience trouble with this equipment, please contact the company that installed the equipment for service and/or repair information. The telephone company may ask you to disconnect this equipment from the network until the problem has been corrected or you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.



# Contents

	<b>Preface</b> .....	<b>ix</b>
	Conventions used in this document.....	ix
	Safety terms and symbols.....	ix
<b>Chapter 1.</b>	<b>Introduction</b> .....	<b>1</b>
	<b>Security system components</b> .....	<b>2</b>
	<b>Communicating with your system</b> .....	<b>4</b>
<b>Chapter 2.</b>	<b>Using the control panel</b> .....	<b>5</b>
	<b>Panel controls</b> .....	<b>6</b>
	Standard text display.....	8
	<b>Simon XT features</b> .....	<b>9</b>
	Things you can do.....	9
	Home security.....	9
	Exit/entry delay.....	11
	Bypassing sensors.....	12
	Alarms.....	13
	Light control (optional).....	14
	Chimes.....	14
	Latchkey.....	15
	System status.....	15
	<b>Using an offsite phone</b> .....	<b>16</b>
	<b>Using touchpads</b> .....	<b>17</b>
	Remote handheld touchpad.....	17
	Keyfob.....	18
<b>Chapter 3.</b>	<b>How your system communicates</b> .....	<b>19</b>
	<b>Status beeps</b> .....	<b>20</b>
	<b>Alarm sirens and lamp modules</b> .....	<b>20</b>
	<b>Panel indicator lights</b> .....	<b>21</b>
	<b>Trouble beeps</b> .....	<b>21</b>
<b>Chapter 4.</b>	<b>Programming</b> .....	<b>23</b>
	<b>System menu</b> .....	<b>24</b>
	Entering and exiting the system menu.....	24
	Code options.....	24
	<b>Menu navigation</b> .....	<b>25</b>
	Set clock.....	26
	Light schedules.....	27
	Sensor lights.....	27
	Chime.....	27
	Special chime.....	28

System tests .....	28
System programming .....	29
Revision .....	36
Contrast .....	36
<b>Chapter 5. Testing .....</b>	<b>37</b>
<b>Testing sensors .....</b>	<b>38</b>
Testing communication .....	39
<b>Appendix A. Reference information .....</b>	<b>41</b>
<b>Alarm system limitations .....</b>	<b>42</b>
<b>Emergency planning .....</b>	<b>42</b>
<b>Smoke and heat detector locations .....</b>	<b>43</b>
<b>Your floorplan .....</b>	<b>44</b>
Sensor and module locations .....	44
Access codes .....	46
Delays .....	46
<b>Index .....</b>	<b>49</b>



## Preface

This is the *GE Simon XT User Manual*. This document includes an overview of the product and detailed instructions on how to operate the system.

Read these instructions and all ancillary documentation entirely before operating this product. The most current versions of this and related documentation may be found on our online publication library. To access the library, go to our website at the following location:

<http://www.gesecurity.com>

In the **Customer Support** menu, select the *Resource Library* link. After you register and log on, you may search through our online library for the documentation you need.<sup>1</sup>

## Conventions used in this document

The following conventions are used in this document:

<b>Bold</b>	Menu items and buttons.
<i>Italic</i>	Emphasis of an instruction or point; special terms.
	File names, path names, windows, panes, tabs, fields, variables, and other GUI elements.
	Titles of books and various documents.
<i>Blue italic</i>	(Electronic version.) Hyperlinks to cross-references, related topics, and URL addresses.
Monospace	Text that displays on the computer screen.
	Programming or coding sequences.

## Safety terms and symbols

These terms may appear in this manual:



**CAUTION:** *Cautions* identify conditions or practices that may result in damage to the equipment or other property.



**WARNING:** *Warnings* identify conditions or practices that could result in equipment damage or serious personal injury.

1. Many GE documents are provided as PDFs (portable document format). To read these documents, you will need Adobe Reader, which can be downloaded free from Adobe's website at [www.adobe.com](http://www.adobe.com).



# Chapter 1 Introduction

This chapter describes the Simon XT's features.


In this chapter:

<i>Security system components</i> .....	2
<i>Communicating with your system</i> .....	4

## Security system components

The Simon XT uses wireless technology to warn your family about intrusion, carbon monoxide, and fire. It may also be used to control lights and appliances within your home. The system communicates with a central monitoring station and sends voice messages to an offsite phone.

Figure 1. Simon XT system



**Note:** The universal, lamp, and appliance modules require a special transformer.

The security system uses sensors that communicate alarms to the control panel using radio waves.

The system is supervised, meaning that the panel checks the status of each sensor to detect problems. If the panel detects trouble, it will notify you with displayed and spoken messages, beeps, and indicator lights on the panel itself.

A Simon *XT* installation may include any of the devices listed in *Table 1*.

Table 1. Simon *XT* system components

Component	Type	Description
Control panel		Operates and programs your security system. It communicates to you through displayed and spoken messages. The panel can communicate to a central monitoring station and send voice messages to your off-site phone.
Touchpads	Remote handheld	Controls the security system primarily from within the home.
	Keyfob	This “keychain touchpad” controls the security system from within or near the outside of your home.
Sensors	Indoor motion	Detects motion in a protected indoor area. When motion is detected, the panel may respond by sounding chimes or an alarm.
	Outdoor motion	Detects motion in a protected outdoor area. When motion is detected, the system may respond by sounding chimes or turning on outside lights. These sensors are not used for intrusion detection.
	Door/window	Detects the opening of a door or window.
	Smoke	Detects smoke or a significant rise in temperature. They have a built-in siren that sounds when smoke or a significant rise in temperature is detected.
	Freeze	Detects furnace failure. If the inside temperature drops below 41°F (5°C), the sensor will notify the panel. The sensor will send a restore signal to the panel when the temperature rises to 50°F (10°C).
	Carbon monoxide	Detects carbon monoxide. They have a built-in siren that sounds when carbon monoxide is detected.
	Water-resistant personal help button	A wireless device used for activating police, medical, or auxiliary alarms through your security system.
Modules	Appliance	Can be programmed to turn appliances or fluorescent lights on and off.
	Lamp	Can be programmed to turn nonfluorescent lights on and off.
	Universal	Used for controlling devices other than appliances and lamps. Check with your installer for other applications.

## Communicating with your system

Sending commands or instructing your security system is done through a series of key presses on the panel, touchpads, or a remote telephone.

Table 2. System communication devices

Device	Description
Control panel	You can enter commands for your security system through simple key presses on the panel. Depending on how your system is programmed, you may need to enter an access code for certain commands. An access code is a numeric code that allows authorization to operate your security system.
Remote handheld touchpad	This touchpad gives you the option to enter commands from any room in your house. You can enter commands through simple key presses on the touchpad.
Keyfob	Keyfobs are handy for simple arming, disarming and light control functions. They are portable and can be carried off-site in a purse or pocket.
Telephone	Touchtone telephones can be used to communicate with your system while you are off-site. Ask your installer if you have this feature.

**Note:** The default master code is 1-2-3-4 when the security system is shipped from the factory. You should change your code after your system is installed. See [Code options](#) on page 24.

## Chapter 2 Using the control panel

This chapter provides instructions for operating your Simon *XT* Security System.

In this chapter:

<i>Panel controls</i> .....	6
<i>Standard text display</i> .....	8
<i>LEDs</i> .....	8
<i>Simon XT features</i> .....	9
<i>Things you can do</i> .....	9
<i>Home security</i> .....	9
<i>Exit/entry delay</i> .....	11
<i>Bypassing sensors</i> .....	12
<i>Alarms</i> .....	13
<i>Light control (optional)</i> .....	14
<i>Chimes</i> .....	14
<i>Latchkey</i> .....	15
<i>System status</i> .....	15
<i>Using an offsite phone</i> .....	16
<i>Using touchpads</i> .....	17
<i>Remote handheld touchpad</i> .....	17
<i>Keyfob</i> .....	18

## Panel controls

You can operate the self-contained security system through several different methods:

- The front panel buttons provide a means of arming and disarming the system when you enter or exit your home. These buttons also provide a method for determining which sensors are active and determining system status.
- A set of three fast action keys provide immediate communication with the central monitoring station to report police, fire, or auxiliary alarms.
- The more complex operating functions are achieved using a combination of the panel buttons and a display menu. This method is used by your installer to establish your system configuration. You can use this method to program certain user features. See *Menu navigation* on page 25.

The self-contained panel (*Figure 2*) provides the user interface for system operation and programming system functions. *Table 3* on page 7 provides a description of the panel keys and display.

Figure 2. Simon XT self-contained panel









Table 3. Simon XT panel keys and features

Control	Description
Piezo siren	The piezo siren makes alarm beeps and status beeps. Fire and intrusion alarm beeps are always played at high volume, while the volume of status beeps (such as trouble or chime beeps, entry and exit delay beeps, or auxiliary alarm beeps) is programmable.
LCD display	The LCD module has a 2 x 16 character array that displays a variety of phrases and icons.
DOORS + WINDOWS	Press to arm perimeter sensors.
MOTIONS	Press to arm interior sensors.
DISARM	Press to turn off intrusion/burglary protection for your system. Only intrusion/burglary sensors such as doors, windows, and motion sensors are disarmed. Environmental sensors, such as smoke and carbon monoxide, stay active at all times.
STATUS	Press to determine system status.
SILENT	Press to silence exit beeps when arming.
BYPASS	Press to bypass a sensor.
Police 	Press and hold the <b>Police</b> button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Emergency 	Press and hold the <b>Emergency</b> button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Fire 	Press and hold the <b>Fire</b> button for two seconds (or press twice quickly) to call the central monitoring station and notify them of a nonmedical call for help.
Microphone	Used to communicate with central monitoring station after an alarm.
Scroll up/scroll down	Press to scroll through lists of similar items.
Enter	Press to select a particular menu item or commit to memory a menu item that has just been programmed.
Numeric keypad	Twelve-key telephone-type keypad (0 through 9, *, #) for entering access codes or other numerical data.
Speaker	Provides voice output and sounds key beeps. The panel speaks arming level changes, system status, and voice chime sensor trips. The panel voice is also used for voice reporting and remote phone control.
Door	Covers the lower panel.
*	Lights on.
#	Lights off.

## Standard text display

While the panel is idle, the following text displays:






Display line 1	Arming level
Display line 2	HH:MMx (Time) and status icons

Arming level text could be one of the following:

- Subdisarmed
- Disarmed
- Doors + Windows
- Motions
- Doors + Windows & Motions

The phrase - *No Delay* is appended to the arming level when no entry delay is active. *Table 4* describes the possible status icons.

Table 4. Status icons

Status icon	Description
	Clock – Light schedules on
	Solid bell – Chime on
	Outlined bell – Special chime on
	Light bulb – Sensor lights on
	Key – Latchkey on

## LEDs

Every key on the front keypad has an LED behind it, except for the scroll up and down keys. There are four status LEDs behind the row of keys below the LCD display. These status LEDs indicate the arming level. There is one status LED behind the **Enter** button. This status LED is lit when there are no open sensors in the system. All other LEDs are controlled as a group and provide backlighting for the keypad for 30 seconds after a key is pressed.

## Simon XT features

Your Simon XT self-contained security system provides the following features:

- Home security
- Entry and exit delays
- Light control
- Emergency
- Bypassing sensors
- Chime
- Latchkey

## Things you can do

The Simon XT features provide you with the ability to perform the following functions:

- Arm perimeter (windows and doors) and interior (motion) sensors to indicate intruders.
- Control lights to be turned on and off at a set time or if an intruder is detected.
- Use one button to send quick response alerts to the central monitoring station.
- Access the system from a keyfob that is similar to that used for your car.
- Access the system from a remote telephone.
- Disable sensors so you can leave a window open while the system is armed.
- Get an audio alert when a protected door is opened while the system is disarmed.
- Have the system notify you if your children do not arrive at home by a predetermined time.

## Home security

The Simon XT allows you to control which sensors are active at any given time. *Table 5* describes the five arming levels that you can set from the control panel.

Table 5. Simon XT arming levels

Level	Function	Description
0	Subdisarm	If your system includes 24-hour protection sensors on items such as gun or jewelry cases, you must subdisarm the panel before accessing these areas to avoid causing an alarm. Environmental sensors, such as smoke and carbon monoxide, stay active at all times.
1	Disarm	In this level, only 24-hour sensors are active.
2	Arm door and window sensors - exterior.	This level arms the door and window sensors, while leaving the interior motion sensors disarmed.
3	Arm motion sensors - interior.	This level allows you to arm the interior motion sensors, while leaving the exterior door and window sensors disarmed.
4	Arm doors, windows and motion sensors -both.	This level allows you to arm the interior motion sensors and the exterior door and window sensors disarmed.

## Arming/disarming

Arming a sensor makes it active and allows the panel to generate an alarm when a door or window is opened, or when an unauthorized person enters a specific area. Disarming makes the sensor inactive in the system. The current arming level is shown on the panel display and changes in arming level are announced on the speaker.

### Subdisarm

1. Enter the master code while the system is disarmed.
2. The panel displays and speaks *Subdisarmed*, the **DISARM** button blinks, and the panel beeps once.
3. When you've finished accessing the temporarily unprotected areas, press **DISARM** to return to *Disarmed*.

### Disarm (off)

1. Press **DISARM**, then enter your code when the panel displays *Enter Code*.
2. The panel displays and speaks *Disarmed*, the **DISARM** button lights up, and the panel beeps once.

### Arming doors and windows

1. Ensure that all doors and windows are closed.
2. Press **DOORS+WINDOWS**, then enter your code when the panel displays *Enter Code*, if a code is required.
3. The panel displays *Doors + Windows*, speaks *Doors and Windows On*, and the **DOORS+WINDOWS** button lights up.
4. The panel starts an exit delay, and sounds exit beeps in groups of 2 until the exit delay expires.

### Arming motion sensors

1. Press **MOTIONS**, then enter your code when the panel displays *Enter Code*, if a code is required.
2. The panel displays *Motions*, speaks *Motions On*, and the **MOTIONS** button lights up.
3. The panel starts an exit delay and sounds exit beeps in groups of 3 until the exit delay expires.

### Arming doors, windows, and motion sensors

1. Press **DOORS +WINDOWS**, then enter your code when the panel displays *Enter Code*, if a code is required.
2. While the panel is in the process of arming, press **MOTIONS**.
3. The panel displays *Doors + Windows & Motions*, speaks *Doors and Windows On, Motions On*, and the **DOORS+WINDOWS** and **MOTIONS** buttons light up.
4. The panel starts an exit delay and sounds exit beeps in groups of 4 until the exit delay expires.

## Exit/entry delay

Your Simon *XT* provides a delay after entering or exiting your home before the system is alarmed. *Table 6* provides details for the entry and exit delay features.

Table 6. Entry and exit delay details

Function	Description
Entry delay	Some active sensors cause immediate alarms when tripped. Other sensors, if enrolled in a delayed response group, start an entry delay that lets you enter the premises and disarm the system. If the system has not been disarmed by the end of the entry delay, the alarm occurs.
No delay	If the system was armed with the No Delay feature activated, there will be no entry delay and the alarm will occur immediately.
Exit delay	When the user arms the system, an exit delay starts. During the delay the user can vacate the premises through a delayed response door without causing an alarm.
Protest during arming	The system may protest an arming level change if certain abnormal conditions exist. If a sensor that is active in the requested arming level is open, the system sounds protest beeps and automatically bypasses the open sensor (depending on system configuration).

### Exit delay

The exit delay is the amount of time the system gives you to exit the home before the system is armed. This is programmed by the installer. After you arm the system you will hear beeps during the exit delay. See *Status beeps* on page 20.

### Silent exit

The silent exit feature silences the status beeps that accompany the exit delay. See *Status beeps* on page 20. Press **SILENT** after you arm the system to silence status beeps. The panel will still beep at the beginning and end of the exit delay.

**Note:** Enabling silent exit doubles the exit delay time.

### Entry delay

The entry delay is the amount of time the system gives you to disarm the system after entering the home. This is programmed by the installer. When you enter your home, you will hear beeps during the entry delay. See *Status beeps* on page 20.

## No entry delay

Use the No Delay feature when you are staying at home, for instance when you are asleep, or when you're away from home and will carry a wireless touchpad that will allow you to disarm the system before opening a protected door. Check with your installer to find out how this option is programmed.

1. Close all doors and windows.
2. Press **DOORS +WINDOWS** twice. If a code is required for arming, enter your code after the first press of the **DOORS +WINDOWS** button, then press the button again.
3. The panel displays *Doors+ Windows - No Delay* and speaks *Doors and Windows On, No Entry Delay*. The **DOORS + WINDOWS** light will blink and the exit delay will begin.

**Note:** To avoid causing an alarm, you must disarm the system with a wireless touchpad before entering your home.

## Quick exit

Use the quick exit feature when someone wants to briefly leave while the home is still armed (for instance to get the newspaper). This feature needs to be enabled by your installer. When you press the **DISARM** button, the display shows *Exit Time Is On*. This allows a designated exit door to be open for up to two minutes without triggering an alarm.

**Note:** The designated door may be opened and closed only once. If you close the designated door behind you when you exit, you will have to disarm the system upon reentering. Leave the designated door open while using the quick exit feature.

## Exit delay extension

If enabled by your installer, the *Exit delay extension* feature will recognize when you arm the system, leave your house and then quickly re-enter your house (such as you would if you forgot your car keys.) In such a case Simon XT will restart your exit delay to give you the full exit delay again.

## Bypassing sensors

Bypassing a sensor allows you to open the sensor while the system is armed. For example, if your *Doors & Windows* are armed and you want to open your kitchen window but do not want to disarm the entire system, then you can bypass the kitchen window sensor and then open the kitchen window without causing an alarm. Bypassed sensors are automatically unbypassed when the arming level is changed to a level where the sensor is not active.

## Bypassing

1. Press **BYPASS** and enter the master code.
2. Scroll up/down until you reach the sensor to be bypassed.
3. The display shows, for example, *Sn 1 Front Door* on the first line.
4. Press **Enter** to bypass (deactivate) the sensor.
5. When a sensor is bypassed, the panel displays *Bypassed* on the second line.

## Unbypassing

1. Press **BYPASS** and enter the master code.
2. Scroll up/down to the sensor to be unbypassed. The sensor must be currently bypassed.
3. Press **Enter** to unbypass (reactivate) the sensor.
4. The panel removes the word *Bypassed* from the second line of the display.

## Alarms

The system provides a series of alarms that indicate an unusual occurrence. When an alarm is active, the panel displays:

*Alarm Alarm Alarm*

*Press Status*

Alarms are canceled by entering a valid master or user code. After alarms are canceled, the system will be disarmed.

## Canceling and preventing accidental alarms

One of the biggest concerns you might have regarding your security system is causing an accidental alarm. Most accidental alarms occur when leaving the residence after arming the system or before disarming the system upon your return.

There is a communicator delay (dialer delay) of 30 seconds programmed into this panel. The panel will delay 30 seconds before dialing the central monitoring station remote phone to send reports. You can have your installer program this delay time between 0 and 254 seconds. To cancel an accidental alarm before the programmed dialer delay time expires, enter your access code.

## Guidelines for preventing accidental alarms

Use the following guidelines to prevent accidental alarms.

- Close doors and windows before you leave your house.
- Gather your belongings, so you can exit immediately after arming the system.
- Always enter and exit within the programmed delay times.
- Make sure you leave through a door that has a delay time set for it.
- Disarm your system immediately upon returning home.
- Be aware of the devices in your security system and learn how each one operates.
- If you have pets, ask your installer if you need pet lenses in your motion detectors.
- Check the location of your smoke detectors. Smoke detectors near bathrooms and kitchens can be tripped by steam and smoke from cooking.
- Make a note of the display, system beeps, and indicator lights that indicate the current system status.

## Light control (optional)

Simon XT lets you control lights and appliances using lamp, appliance, or universal modules. You can:

- Turn lights with unit numbers 1 to 8 on or off manually or at a specific time.
- Turn on lights when a sensor is tripped. You can program lockout times when sensor-activated lights won't be active.

To turn on all of the lights that are controlled by lamp modules, press the \* button twice. The panel display will show *All Lights On*. To turn off all lights that are controlled by lamp modules, press the # button twice. The panel display will show *All Lights Off*. To turn on or off individual lights:

- To turn on a light with unit number N (1 to 8), press the \* button, then <N>. The panel displays and speaks *Light <N> On*.
- To turn off a light with unit number N (1 to 8), press the # button, then <N>. The panel displays and speaks *Light <N> Off*.

## Chimes

Use the *Chime* feature to signal when a protected door is opened while the system is disarmed. The panel chimes twice when a chime sensor is tripped, if the chime mode is enabled. This feature allows you to be notified when family members are going in and out of your home. The *Chime* and *Special Chime* features are turned on or off in the system menu. See [Chime](#) on page 27 and [Special chime](#) on page 28.

**Note:** If there are no chime sensors in your system, the *Chime* option will not be in the System menu.

## Voice chime

Your installer may have programmed the system to speak the sensor name or make a custom chime sound when a chime sensor is tripped. The chime sound, if programmed, will be played in place of the standard chime beeps.

## Special chime

Special chime allows you to install motion sensors in a patio or at the front door, and be notified when someone is approaching those areas. These motion sensors are not used for intrusion protection. The panel will chime three times, if the special chime mode is enabled.

**Note:** If there are no special chime sensors in your system, the *Special Chime* option will not be shown in the System menu.



## Latchkey

Use the latchkey feature to notify you, via a remote phone, if a family member does not arrive home at a predetermined time and disarm the system. When this feature is active, a latchkey alarm is reported if the premises are not disarmed by the programmed latchkey time. For example, if you set the Latchkey time for 3:00 p.m. and the system is not disarmed by that time a message is sent to your remote phone. The latchkey feature can be activated during arming if a latchkey time is programmed.

To activate the latchkey feature:

1. Press **MOTIONS** twice. If a code is required, enter your code after the first press of the **MOTIONS** button, then press **MOTIONS** a second time.
2. The panel **MOTIONS** light will blink and the exit delay will begin.

## System status

Press **STATUS** (no code is required) to cause the system to display and speak the following types of information:

- Alarm conditions
- Alarm history
- Trouble conditions
- Open sensors
- Bypassed sensors

The **STATUS** button blinks when an active alarm exists. The **STATUS** button is lit when an abnormal condition such as a trouble or open sensor exists in the system.

You can clear certain status entries from the system (such as old alarm history) by pressing **DISARM** after checking the status.

## Using an offsite phone

If enabled by the installer, you can control your Simon XT panel remotely from an offsite phone. The panel answers a phone call according to the dialing method programmed by your installer.

After a certain combination of rings and pauses, the panel will answer the call with the voice prompt *Enter your code*. You must enter the correct code to gain access.

If you are interacting with your panel and the panel hangs up on you, the system is calling in a report to the central monitoring station or remote phone due to an action by you or someone at the security system site. The actions listed in *Table 7* may be performed from an offsite phone.

Table 7. Phone controls

Action	Phone key presses	Comments
Disarm	①	System not already disarmed
Subdisarm	①	Must have used the master code to gain access; system was disarmed
Arm doors and windows	②	Press 2 again to activate <i>No Delay</i> feature
Arm motion sensors	③	Press 3 again to activate <i>Latchkey</i> feature
Arm doors, windows, and motion sensors	② - ③	
Check status	①	
Turn light on	*-<unit_num>.	N = 1-8, unit number
Turn light off	#-<unit_num>.	N = 1-8, unit number
Turn all lights on	* - *	
Turn all lights off	# - #	
Hang up	⑨	


## Using touchpads

Touchpads are used to control the security system from any location within or near your home.

### Remote handheld touchpad

Interfacing with the system using a remote handheld touchpad is similar to using the panel.

Figure 3. Remote handheld touchpad



## Keyfob


If your installer programmed the keyfob with no entry delay, and you armed the system with the keyfob, you must disarm your system before entering the home to avoid causing an alarm.

---

**CAUTION:** To avoid causing false alarms, check with your installer on how your touchpad options are programmed.

---












Figure 4. Keyfob (keychain touchpad)



**Note:** For any key press on the keyfob, hold the button until the indicator light blinks

If your installer programmed your system for remote touchpad arming, you must enter your home to start the entry delay before you can use your keyfob to disarm the system.

**Note:** Panic alarms need to be silenced from the panel, a remote handheld touchpad, or another keyfob. They cannot be silenced from the same keyfob that activated the alarm.

	Lock	Press once to arm doors and windows.
 - 	Lock	Press twice to arm doors, windows, and motion sensors.
 -  - 	Lock	Press three times to arm doors, windows, motion sensors, and to activate the latchkey option.
 +  Hold both for 3 sec.	Lock and unlock	Press both buttons simultaneously for three seconds to send a panic (intrusion, silent, or nonmedical emergency) alarm to the central monitoring station. Check with the installer to find out how the keyfob panic buttons will operate.
	Unlock	Press to disarm your security system.
	Star	Can be programmed to control a device connected to a universal module.
	Light	Can be programmed to control a device connected to a lamp module. Press once to turn on all lights on lamp module. Press again to turn off all lights on lamp module turn off.

# Chapter 3 How your system communicates

Your system responds to you through the use of display and voice messages, status beeps, alarms, and panel indicator lights.

In this chapter:

- Status beeps* .....20
- Alarm sirens and lamp modules* .....20
- Panel indicator lights* .....21
- Trouble beeps*.....21
  - AC power failure*.....21
  - System battery failure* .....21
  - Restoration of power*.....22
  - Sensor failure* .....22
  - Sensor low battery*.....22
  - Fail-to-communicate*.....22
  - Sensor open*.....22
  - Sensor tampered* .....22
  - RF jam detected* .....22
  - Clearing status* .....22

## Status beeps

The panel sounds status beeps to alert you to various system events and conditions.

**Note:** You may receive a different number of status beeps if you press the buttons quickly.

Table 8. Status beeps

Activity	Beep Response
Doors + Windows	<b>Exit delay</b> and <b>Entry delay</b> beeps sound two times every five seconds and two times per second during the last ten seconds. If silent exit is used, the exit delay beeps will only sound twice when you arm and twice when the exit delay expires.
Motions	<b>Exit delay</b> and <b>Entry delay</b> beeps sound three times every five seconds and three times per second during the last ten seconds. If silent exit is used, the exit delay beeps will only sound three times when you arm and three times when the exit delay expires.
Doors + Windows and Motions	<b>Exit delay</b> and <b>Entry delay</b> beeps sound four times every five seconds and four times per second during the last ten seconds. If silent exit is used, the exit delay beeps will only sound four times when you arm and four times when the exit delay expires.
Disarm	One beep.
Chime	Two beeps.
Special chime	Three beeps.
Trouble beeps	Six beeps every minute. Press <b>STATUS</b> to stop beeps for four hours.
No activity beeps	Twenty beeps every minute for five minutes. Feature must be programmed by the installer.

## Alarm sirens and lamp modules

Exterior and interior sirens make three different alarm sounds on the premises, each indicating a different type of alarm. Sirens are programmed by the installer to time out and stop sounding after a specified time.

Use *Table 9* to understand the siren sounds used by the security system.

Table 9. Alarm Siren and X10 Light Information






Function	Fire	Intrusion	Emergency
X10 Lights	Steady	Flashing	Steady
X10 Siren	Steady	Steady	Alarm beeps
Interior and panel siren	Temporal 3 <sup>a</sup>	Steady	Fast on/off
Exterior siren	Temporal 3 <sup>a</sup>	Steady	

a. Temporal 3 refers to a continuous pattern of three siren pulses, then off for 1.5 seconds, three siren pulses, then off for 1.5 seconds.

## Panel indicator lights

Use *Table 10* to understand the panel indicator lights.

Table 10. Panel indicator lights

Button	When button light is on	When the button flashes
DOORS+WINDOWS	Doors + Windows armed	Doors + Windows armed and no entry delay on
MOTIONS	Motions armed	Motion sensors armed and latchkey on
DISARM	System disarmed	System subdisarmed
STATUS	System trouble, open sensor, or bypassed sensor	System in alarm
Enter	There are no open sensors	
 Chime - Solid bell	Door will cause chime	
 Special chime - Outlined bell	Motion will cause chime	
 Light schedules - Clock	Time-activated lights feature enabled	
 Sensor lights - Light bulb	Sensor-activated lights feature enabled	
 Latchkey on - Key	Latchkey feature enabled	

## Trouble beeps

Your security system is able to automatically test itself for:

- Power failures
- Low batteries
- Nonworking sensors
- Communication troubles with the central monitoring station

When your security system detects one of the problems above, six rapid beeps sound every minute until the trouble condition is corrected. To stop the trouble beeps, press **STATUS** or arm/disarm the system while the trouble condition exists. Trouble beeps will resume four hours later unless the trouble condition is corrected.

The following list explains the trouble beep conditions:

**AC power failure.** This condition (if programmed by installer) occurs if your security system has been accidentally unplugged or if there has been an AC power outage. Any status lights go out immediately, and trouble beeps start after five minutes. If you press any button, the display will light and pressing **STATUS** will show the AC failure. If AC power is not restored within a programmed period of time (5 to 254 minutes) the system will call the central monitoring station. The backup battery, if fully charged, will last for 18 to 24 hours — depending on the load applied to the panel — with no AC power.

**System battery failure.** This condition occurs if the emergency backup battery has failed. Trouble beeps will start. Press the **STATUS** button and the display will show *System Low Battery*. If your AC power is not working, your security system will shut down once the battery has failed. If the condition does not clear after AC power has been restored and 24 hours have passed, call your security system dealer.

**Restoration of power.** This condition occurs after a complete loss of power (AC and battery). When power is restored, the panel will return to the arming state with the same zones bypassed it had prior to losing power.

**Sensor failure.** This condition occurs if a sensor is not communicating with the panel. Trouble beeps will start and the **STATUS** button will light. Press the **STATUS** button and the display will show what sensors have failed. Perform sensor tests. You may need to call your security system dealer if the problem continues.

**Sensor low battery.** This condition occurs if a system sensor has a low battery. The sensor may still be communicating with the panel. Trouble beeps will start and the **STATUS** button will light. Press the **STATUS** button and the display will show what sensors have a low battery. You may need to call your security system dealer to resolve this problem. Some sensor batteries can be replaced by the homeowner.

**Fail-to-communicate.** This condition occurs if your security system cannot communicate to the central monitoring station. Your system will try to report to the central monitoring station eight times before it tells you there is a fail-to-communicate problem. Trouble beeps will start and the **STATUS** button will light. Press the **STATUS** button and the display will show *Comm Test Fail* or *Comm Failure*. You may need to call your security system dealer if the problem continues.

**Sensor open.** This condition occurs if a door or window is open or a system sensor has been disturbed and not reset properly. For example, a door/window sensor magnet may have been removed from the sensor. Your system will indicate this condition to you by causing the **STATUS** button to light. When you press the **STATUS** button, the display shows, for example, *Sn 1 Front Door Open*. Correct the problem by resetting the sensor. If this condition continues, call your security system dealer.

**Sensor tampered.** This condition occurs when a sensor is physically tampered with, for example, the cover is taken off of one of the sensors. If the system is armed an alarm will occur. Your system will indicate this condition to you by causing the **STATUS** button to light. Trouble beeps will start. Press the **STATUS** button and the display shows *Sn # Name Tampered*. Correct the problem by resetting the sensor. If this condition continues, call your security system dealer.

**RF jam detected.** The panel receiver may be experiencing some interference. The system will call to notify the central monitoring station about this problem.

**Clearing status.** Some types of status conditions, such as the alarm history, must be cleared manually. To clear system status, press the **STATUS** button, read and/or listen to the status messages, then press **DISARM**. If the trouble condition was a low system battery, perform a sensor test. The **STATUS** light should turn off if all trouble conditions have been corrected.



# Chapter 4 Programming

This chapter describes how to program your system. It will guide you through programming instructions for system features.

<i>System menu</i> .....	24
<i>Entering and exiting the system menu</i> .....	24
<i>Code options</i> .....	24
<i>Menu navigation</i> .....	25
<i>Set clock</i> .....	26
<i>Light schedules</i> .....	27
<i>Sensor lights</i> .....	27
<i>Chime</i> .....	27
<i>Special chime</i> .....	28
<i>System tests</i> .....	28
<i>System programming</i> .....	29
<i>Revision</i> .....	36
<i>Contrast</i> .....	36

## System menu

Your Simon *XT* self-contained security system security system allows you to program certain user options, such as access codes, time schedules, or the system time. These options are accessed through a system menu.

### Entering and exiting the system menu

To enter the system menu, press the scroll up/down buttons or the **Enter** button in the upper right of the panel.

Press **STATUS** to exit a menu or option edit mode and navigate up one level. Pressing **STATUS** while in the top menu level exits the system menu. The panel automatically exits the system menu after a few seconds of inactivity if no access code has been entered yet. After an access code has been entered to access a code-protected area of the system menu, the timeout is 30 seconds (4 minutes while performing a sensor test).

### Code options

The Simon *XT* security system provides a system of codes to be entered when a certain level of authority is required to perform an action. These codes allow you to activate system options, customize panel operations, and generate a silent alarm. The default code is based on the code length (3, 4, 5, or 6-digit code) determined at installation. The code types are listed in *Table 11*.

Table 11. Simon XT system codes

Code	Description
Master code	The master code is the main code used for panel operations. The default code will be 123, 1234, 12345, or 123456 depending on the value set by the installer for code length.
User codes 1 through 8	These eight codes are supplemental user codes. These codes can be used for panel operations such as disarming, but not programming. These codes can be any 3, 4, 5, or 6-digit code, depending on the code length.
Duress code	the duress code is used to generate a silent duress alarm while disarming.

**Note:** Any combination of invalid codes in excess of 40 key presses (such as fourteen invalid three-digit codes) will cause a system access alarm. The alarm locks all touchpads, except keyfobs, for 90 seconds.

## Menu navigation

Each menu contains a list of options and/or submenus. Press the scroll up/down buttons to navigate up and down the list of options and submenus in that menu. Pressing **Enter** after navigating to an option selects that option for editing and flashes the current value. Pressing **Enter** after navigating to a submenu enters that submenu, making a new list of options accessible. Pressing **STATUS** exits a menu and goes to the next higher level.

Programming options are arranged in a menu structure as outlined in *Table 12*. The top menu contains several features, as well as the *System Programming* menu. When accessing the *System Programming* or *System Tests* menu, the panel prompts you to enter an access code. To continue, enter the master code, then press **Enter**.

To program an option, first navigate to that option until it is displayed, then press **Enter**. The option value will start flashing, indicating that it is ready to be changed. Use the scroll keys or enter a numerical value to change the option, then press the **Enter** key to save the change.

Table 12. Simon XT system menu structure

Top menu entry	First submenu level	Second submenu level
Set Clock		
Light Schedules		
Sensor Lights		
Chime		
Special Chime		
System Tests	Sensor Test Comm Test System Download	
System Programming	Access Codes	Master Code User Code 1 to 8 Duress Code
	Security	Download Enable
	Phone #s	Phone #4
	Timers	Latchkey Time
	Siren Options	Piezo Beeps Panel Voice Panel Piezo Alrm Status Beep Vol Speaker Volume
	Light Control	Set Entry Lights Sensor Light Light Schedules Housecode Lock Interval

Table 12. Simon XT system menu structure (continued)

Top menu entry	First submenu level	Second submenu level
	System Tests	Sensor Test Comm Test System Download
Revision		
Contrast		

## Set clock

If the panel loses both AC and battery power, then upon restoring power the system time will default to midnight and blink, indicating it has not been set correctly. Your installer can set your system time to display in either 12-hour or 24-hour format.

Time of day format is HH:MMx

Where:

HH = 01 to 12 (12-hour format) or 00-23 (24-hour format)

MM = 00 to 59

x = a or p (12-hour format) or none (24-hour format)

To reset the clock:

1. Scroll up/down until the display shows *Set Clock*.
2. Press **Enter**.
3. The display shows *Enter Code*.
4. Enter your master code with numeric keys. Press **Enter**.
5. Press **Enter** again. The display now flashes the hours.
6. Scroll up/down to set the hours.
7. Press the **Enter** key to accept. The display now flashes the minutes.
8. Scroll up/down to set the minutes.
9. Press the **Enter** key to accept. The display is now flashing the AM/PM.
10. Scroll up/down to set the AM/PM.
11. Press **Enter** to accept. The display now shows the current time, and stops flashing.
12. Press **STATUS** twice to exit.

## Light schedules

Simon *XT* will automatically turn certain lights on or off according to light schedules you can define in menu item *System Programming / Light Control / Light Schedules*. See *Light control (optional)* on page 14.

To enable or disable scheduled lights:

1. Scroll up/down until the display reads *Light Schedules*.
2. Press **Enter**. The current setting will flash.
3. Scroll up/down to toggle scheduled lights *On/Off*.
4. Press **Enter**. The setting will stop flashing.
5. Press **STATUS** to exit.

A clock icon appears in the display when *scheduled lights* are enabled.

**Note:** This menu option will not appear if no *light schedules* are defined.

## Sensor lights

Simon *XT* automatically turns certain lights on or off when certain sensors are tripped. For example, you can set a basement light to turn on when the door to the basement is opened. You can associate sensors with lights in menu item *System Programming / Light Control / Sensor Light*. See *Light control (optional)* on page 14.

To enable or disable sensor-activated lights:

1. Scroll up/down until the display shows *Sensor Lights*.
2. Press **Enter**. The current setting will flash.
3. Scroll up/down to toggle the sensor-activated lights *On/Off*.
4. Press **Enter**. The setting will stop flashing.
5. Press **STATUS** to exit.

A light-bulb icon will appear in the display when *Sensor Lights* are enabled.

**Note:** This menu option will not appear if no *sensor lights* have been defined.

## Chime

To enable or disable the *Chime* feature:

1. Scroll up/down until the display shows *Chime*.
2. Press **Enter**. The current setting will flash.
3. Scroll up/down to toggle *Chime On/Off*.
4. Press **Enter**. The setting will stop flashing.
5. Press **STATUS** to exit.

A solid bell icon will appear in the display when *Chime* is enabled.

**Note:** This menu option will not appear if no chime sensors are in your system

## Special chime

To enable or disable the *Special Chime* feature:

1. Scroll up/down until the display shows *Chime*.
2. Press **Enter**. The current setting will flash.
3. Scroll up/down to toggle *Special Chime On/Off*.
4. Press **Enter**. The setting will stop flashing.
5. Press **STATUS** to exit.

An outlined bell icon will appear in the display when *Special Chime* is enabled.

**Note:** This menu will not appear if *Special Chime* sensors are not in your system.

## System tests

The Simon XT system tests include:

- Sensor Test (see *Testing sensors* on page 38)
- Comm Test (see *Testing communication* on page 39)
- System download

## System download

You can initiate a download call to program your system with the settings specified by your installer.

To initiate a download:

1. Scroll up/down till the display shows *System Tests*.
2. Press **Enter**. The display shows *Enter Code*.
3. Enter your master code with numeric keys.
4. Press **Enter**. The display now shows *Sensor Test*.
5. Scroll up/down till the display shows *System Download*.
6. Press **Enter**. The display shows *Download In Progress*.
7. Wait while your system calls the download center.
8. Display will show the result of the download. If the display shows *Download Fail*, contact your dealer.
9. Press **STATUS** twice to exit.

**Note:** Use this feature only when instructed by your installer or dealer.

## System programming

To enter the *System Programming* menu:

1. Enter the system menu.
2. Scroll up/down to *System Programming*, then press **Enter**.
3. The panel displays *Enter Code*.
4. Enter your master code, then press **Enter**.

At this point, you are in the *System Programming* submenu. At this level, the following items are accessible:

- Access Codes
- Security
- Phone #s
- Timers
- Siren Options
- Light Control
- System Tests

The sections below describe the options that you can program in the *System Programming* menu.

### Access codes

There are three types of access codes: master, user, and duress.

- The master code is your most powerful code and can be used for all user operations including programming
- There are eight user codes, which can be used for many user operations, but not subdisarming, programming, or bypassing sensors.
- The duress code, when used in place of another user code, generates a silent duress alarm which is reported to the central monitoring station.

### Master code

To change the master code:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Access Codes*, then press **Enter**.
3. Scroll up/down to *Master Code*, then press **Enter**.
4. The current value of the code now flashes.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **STATUS** repeatedly to exit.

The initial value of the master code is 123, 1234, 12345, or 123456, depending on the installer-programmed access code length.

### User codes 1 to 8

To change a user code:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Access Codes*, then press **Enter**.
3. Scroll up/down to the user code you want to change, then press **Enter**.
4. The current value of the code now flashes.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **STATUS** repeatedly to exit.

Initially, all user codes are blank. A user code can be deleted by pressing **DISARM** while the code is being changed.

### Duress code

To change the duress code:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Access Codes*, then press **Enter**.
3. Scroll up/down to *Duress Code*, then press **Enter**.
4. The current value of the code now flashes.
5. Enter a new code (use correct length), then press **Enter**.
6. Press **STATUS** repeatedly to exit.

Initially, the duress code is blank. The duress code can be deleted by pressing **DISARM** while the code is being changed.

### Security

The *Security* menu contains the *Download Enable* option. This option determines whether your dealer can access the system remotely.

To program the *Download Enable* option:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Security*, then press **Enter**.
3. Scroll up/down to *Download Enable*, then press **Enter**.
4. The current value of this option now flashes *On/Off*.
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.



## Phone numbers

*Phone #4* is the only system phone number that you can change. Therefore, it is often used for voice reporting of alarms to your phone, if it was programmed for this purpose by the installer.

To change *Phone #4*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Phone #s*, then press **Enter**.
3. Scroll up/down to *Phone #4*, then press **Enter**.
4. The first digit of the current value of this option now flashes (this may take up both lines on the display).
5. Change each digit of the phone number by scrolling or entering a numerical value, then move to the next digit by pressing **Enter**.
6. When done, press **Enter** again to save the new phone number.
7. Press **STATUS** repeatedly to exit.

The phone number can be deleted by pressing the **DISARM** button while changing a digit.

## Timers

The *Latchkey Time* option is the only timer setting available to you. The *Latchkey Time* is the time of day by which the panel must be disarmed to avoid triggering a latchkey alarm, if the *Latchkey Time* option is enabled during arming.

To change the *Latchkey Time*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Timers*, then press **Enter**.
3. Scroll up/down to *Latchkey Time*, then press **Enter**.
4. The *HH* (hours) part of the time now flashes.
5. Program the hour value by scrolling or entering a numerical value, then press **Enter**.
6. The *MM* (minutes) part of the time now flashes.
7. Program the minute value by scrolling or entering a numerical value, then press **Enter**.
8. If you are using 12-hour clock format, the *a* or *p* (AM/PM) part of the time now flashes.
9. Select *a* or *p* by scrolling, then press **Enter**.
10. Press **STATUS** repeatedly to exit.

## Siren options

The panel has two built-in sound sources, a piezo siren and a speaker. The piezo siren makes alarm beeps and status beeps. Fire and intrusion alarm beeps are always played at high volume, while the volume of status beeps (such as trouble or chime beeps, entry and exit delay beeps, or auxiliary alarm beeps) is programmable. The speaker emits the panel's voice and also sounds beeps when a key is pressed. Its volume is also programmable.

The siren and built-in speaker options consist of the following:

- Panel piezo beeps (status beeps sounded on the siren)
- Panel voice (spoken phrases on the speaker) and key press sounds from the speaker heard while controlling the system)
- Panel piezo alarms (loud alarms on the siren)
- Status beep volume
- Speaker volume

### Piezo Beeps

This option determines whether or not the panel sounds non-alarm beeps.

To program *Piezo Beeps*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Siren Options*, then press **Enter**.
3. Scroll up/down to *Piezo Beeps*, then press **Enter**.
4. The current value of this option now flashes (On or Off).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

### Panel Voice

This option determines whether or not the panel speaks status messages and arming level changes.

To program *Panel Voice*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Siren Options*, then press **Enter**.
3. Scroll up/down to *Panel Voice*, then press **Enter**.
4. The current value of this option now flashes (On or Off).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

### Panel Piezo Alarm

This option determines whether or not the panel sounds alarm beeps.

To program *Panel Piezo Alarm*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Siren Options*, then press **Enter**.
3. Scroll up/down to *Panel Piezo Alarm*, then press **Enter**.
4. The current value of this option now flashes (On or Off).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

### Status Beep Vol

This option sets the sound volume of nonalarm beeps. The numerical range is 1 to 10. The default value is 7.

To program *Status Beep Vol*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Siren Options*, then press **Enter**.
3. Scroll up/down to *Status Beep Vol*, then press **Enter**.
4. The current value of this option now flashes (1 to 10).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

### Speaker Volume

This option sets the sound volume of the panel speaker for key presses and alarm sounds. The numerical range is 1 to 8. The default value is 8.

To program *Speaker Volume*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Siren Options*, then press **Enter**.
3. Scroll up/down to *Speaker Volume*, then press **Enter**.
4. The current value of this option now flashes (1 to 8).
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

## Light control (optional)

You can control certain lights by using X-10 lamp, appliance, or universal modules. As set up by the installer, these modules have unit numbers from 1 to 8 and are set to the same housecode. These lights can be turned on for certain arming operations, when a sensor is tripped or based on a time schedule. *Light Control* includes:

- Set entry lights
- Sensor lights
- Light schedules
- Housecode
- Sensor-activated light lockout time

### Set Entry Lights

In this menu, each unit number can be set up as an entry light. These lights flash the arming level when the system is armed. For example, an entry light flashes twice when the system is armed to Level 2 (*Doors+Windows*).

To *Set Entry Lights*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Light Control*, then press **Enter**.
3. Scroll up/down to *Set Entry Lights*, then press **Enter**.
4. Scroll up/down to the unit number you want to set up, then press **Enter**.
5. The current option value flashes (On or Off).
6. Scroll up/down to the desired value, then press **Enter**.
7. Press **STATUS** repeatedly to exit.

### Sensor Light

In this menu, each sensor can be tied to a unit number. For example, a light in a room can be set up to turn on when a motion sensor in that room is tripped.

To set up *Sensor Light*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Light Control*, then press **Enter**.
3. Scroll up/down to *Sensor Light*, then press **Enter**.
4. The number and name of the first sensor are displayed, along with its associated unit number.
5. Scroll up/down to the sensor you want to set up, then press **Enter**.
6. The current option value now flashes (1 to 8 or Off).
7. Scroll up/down to the desired value or enter a numerical value, then press **Enter**.
8. Press **STATUS** repeatedly to exit.

## Light Schedules

In this menu, a light schedule can be programmed for each unit number (1 to 8).

To program *Light Schedules*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Light Control*, then press **Enter**.
3. Scroll up/down to *Light Schedules*, then press **Enter**.
4. Scroll up/down to the desired light schedule (as defined by the unit number), then press **Enter**.
5. The current option value now flashes.
6. Enter the desired start time by entering the hours, minutes, and AM/PM (press **Enter** after programming each part).
7. Enter the desired end time by entering the hours, minutes, and AM/PM (press **Enter** after programming each part).
8. Press **STATUS** repeatedly to exit.

## Housecode

To change the *Housecode*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Light Control*, then press **Enter**.
3. Scroll up/down to *Housecode*, then press **Enter**.
4. The current option value (A to O) now flashes.
5. Scroll up/down to the desired value, then press **Enter**.
6. Press **STATUS** repeatedly to exit.

## Lock Interval

Each light (unit numbers 1 to 8) that has been tied to a sensor can be programmed not to turn on during a certain time of day.

To program the *Lock Interval*:

1. Enter the *System Programming* menu.
2. Scroll up/down to *Light Control*, then press **Enter**.
3. Scroll up/down to *Lock Interval*, then press **Enter**.
4. Scroll up/down to the unit number for which you want to program a lockout time, then press **Enter**.
5. The current option value now flashes.
6. Program the start and end times (see *Light Schedules* on page 35).
7. Press **STATUS** repeatedly to exit.

## System Tests

This menu duplicates a higher-level menu. For more information, see *System tests* on page 28.

## Revision

To display the firmware revision of the system:

1. Scroll up/down to *Revision*.
2. Press **STATUS** to exit.

## Contrast

To adjust the *Contrast* of the display:

1. Scroll up/down to *Contrast*.
2. press **Enter**.
3. Scroll up/down to increase and decrease the contrast setting.
4. Press **STATUS** to save the setting and exit.

**Note:** Changes in contrast are more noticeable when not looking at the display straight-on.

# Chapter 5 Testing

This chapter provides a set of tests to ensure proper operation of your Simon *XT* self-contained security system. We recommended you test your system weekly.

<i>Testing sensors</i> .....	38
<i>Testing communication</i> .....	39

## Testing sensors

You can test sensors one at a time to make sure they are sending strong signals to the panel. You should test the security system at least once a week.

To perform the *Sensor Test*:

1. Scroll to *System Tests*.
2. Press **Enter**. The display shows *Enter Code*.
3. Enter your master code with the numbered keys.
4. Press **Enter** to accept the master code. The display shows *Sensor Test*.
5. Press **Enter**. The display shows, for example, *Trip Sn 1 Front Door* and automatically displays the list of sensors to be tested. The panel sounds six beeps once a minute while in *Sensor Test* mode. See [Table 13, How to trip devices for sensor test](#) on page 38.

When you trip a sensor the display shows, for example, *Sn 1 Packets = 8 Front Door*. You may trip the sensors in any order. As each sensor is heard from, it is removed from the list of sensors to be tested.

After all sensors have been successfully tested, the display shows *Sn Test Complete, Press Status*. To terminate the sensor test:

1. Press **STATUS**. The display shows *Sensor Test Ok*.
2. After a few seconds the display shows *Sensor Test*.
3. Press **STATUS** repeatedly to exit.

If any of the sensors did not test successfully and you want to terminate the test, press **STATUS**. The panel display will show *Sensor Test Fail or Aborted*. The display then shows *Sensor Test*. Press **STATUS** once to exit the system test. If a sensor test fails, call your security dealer.

Table 13. How to trip devices for sensor test

Device	To trip device
Door/window sensor	Open the secured door or window.
Freeze sensor	Apply ice to the sensor. Do not allow the sensor to get wet.
Water sensor	Press a wet rag or wet finger over both of the round, gold-plated terminals on the underside of the sensor.
Carbon monoxide sensor	Unplug the CO alarm. Plug it back in and press the test/reset button until the unit beeps 8 times.
Glass guard sensor	Tap the glass 3 or 4 inches (6 to 8 cm) from the sensor.
Motion sensor	Avoid the motion sensor's view for five minutes, then enter its view.
Shock sensor	Tap the glass twice, away from the sensor. Wait at least 30 seconds before testing again.
Smoke sensor	Press and hold the test button until the system sounds transmission beeps.
Wireless panic button	Press and hold the appropriate panic button for three seconds.
keyfob	Press and hold lock and unlock simultaneously for three seconds.
Remote handheld touchpad	Press and hold the two emergency buttons simultaneously for three seconds.



## Testing communication

Test communication between your system and the central monitoring station or a voice report destination at least once per week to make sure you have the proper telephone connection.

To perform a communication test:

1. Scroll to *System Tests*.
2. Press **Enter**. The display shows *Enter Code*.
3. Enter the master code.
4. Press **Enter** to accept the master code. The display shows *Comm Test*.
5. Scroll to *Comm Test*.
6. Press **Enter**. The display shows *Comm Test is On*.
7. After the communication test is successful, the display shows *Comm Test Ok*.
8. Press **STATUS** repeatedly to exit.

**Note:** If your system is not connected to a central monitoring station and you do not have a voice report destination programmed, you won't be able to perform the communication test.

If the communication test is successful, the system displays *Comm Test Ok*. If the test is unsuccessful, the **STATUS** button will light and within ten minutes the panel will display *Comm Failure*. If a communication test fails, call your security system dealer.



# Appendix A Reference information

This appendix provides a list of system limitations, emergency planning, floorplan, and a quick reference command table.

In this appendix:

<i>Alarm system limitations</i> .....	42
<i>Emergency planning</i> .....	42
<i>Smoke and heat detector locations</i> .....	43
<i>Your floorplan</i> .....	44
<i>Sensor and module locations</i> .....	44
<i>Access codes</i> .....	46
<i>Delays</i> .....	46
<i>Simon XT system quick reference</i> .....	47

## Alarm system limitations

Not even the most advanced alarm system can guarantee protection against burglary, fire, or environmental problems. All alarm systems are subject to possible compromise or failure-to-warn for a variety of reasons.

- If sirens are not placed within hearing range of persons sleeping, in remote parts of the premises, or if they are placed behind doors or other obstacles.
- If intruders gain access through unprotected points of entry or areas where sensors have been bypassed.
- If intruders have the technical means of bypassing, jamming, or disconnecting all or part of the system.
- If power to sensors is inadequate or disconnected.
- If freeze or any environmental sensors are not located in areas where the appropriate condition can be detected.
- If smoke does not reach a smoke sensor. For example, smoke sensors cannot detect smoke in chimneys, walls, roofs, or areas blocked by a closed door. Sensors may not detect smoke in other levels of the building. Sensors may not warn in time when fires are caused by smoking in bed, explosions, improper storage of flammables, overloaded electrical circuits, or other hazardous conditions.
- If telephone lines are out of service.

Inadequate maintenance is the most common cause of alarm failure. Therefore, test your system at least once per week to be sure sensors, sirens, and phone communication are all working correctly.

Although having an alarm system may make you eligible for reduced insurance premiums, the system is no substitute for insurance.



**WARNING:** Security system devices cannot compensate you for the loss of life or property.

---

## Emergency planning

Since an emergency is always unexpected, you should develop plans to help prepare for a variety of emergency situations. Periodically discuss and rehearse emergency plans to include the following:

- Understand how to use your security system.
- Know the normal state of doors and windows: open, closed, or locked.
- Escape fast! (Do not stop to pack.)
- Use a different escape route if closed doors feel hot to the touch.
- Crawl and hold your breath as much as possible to help reduce smoke inhalation during your escape.
- Meet at a designated outdoor location.
- Emphasize that no one should return to the premises if there is a fire.
- Notify the fire department from a neighbor's phone.
- Emphasize that no one should enter the premises if they hear sirens in the house.
- If you arrive at the premises and hear sirens, do not enter. Call for emergency assistance from a neighbor's phone.


## Smoke and heat detector locations

Selecting a suitable location is critical to the operation of smoke alarms. *Figure 5* shows some typical floorplans with recommended smoke and heat detector locations. Use these location guidelines to optimize performance and reduce the chance of false alarms:

- Before mounting alarms, program (learn) them into memory and do a sensor test from the alarm's intended location to ensure good RF communication to the panel.
- Locate the alarm in environmentally controlled areas where the temperature range is between 40 and 100°F (5 and 38°C) and the humidity is between 0 and 90% noncondensing.
- Locate alarms away from ventilation sources that can prevent smoke from reaching the alarm.
- Locate ceiling mounted alarms in the center of the room or hallway, at least 4 in. (10 cm) away from any walls or partitions.
- Locate wall mounted alarms so the top of the alarm is 4 to 12 in. (10 to 31 cm) below the ceiling.
- In rooms with sloped, peaked, or gabled ceilings, locate alarms 3 ft. (0.9 m) down or away from the highest point of the ceiling.
- When mounting to suspended ceiling tile, the tile must be secured with the appropriate fasteners to prevent tile removal.

**Note:** Do not mount the alarm to the metal runners of suspended ceiling grids. The metal runners can draw the magnet's field away from the alarm's reed switch and cause a false tamper alarm.

Figure 5. Smoke detector locations



## Your floorplan

Use the following guidelines when drawing your floorplan:

- Show all building levels.
- Show exits from each room (two exits per room are recommended).
- Show the location of all security system components.
- Show the location of any fire extinguishers

## Sensor and module locations

Use *Table 14* and *Table 15* on page 45 to list your sensor and module locations.

Table 14. Sensor locations

Sensor number	Sensor name	Sensor type	Location
Example	Front door	Door/window sensor	Front door
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			

Table 14. Sensor locations (continued)

Sensor number	Sensor name	Sensor type	Location
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			

Table 15. X10 module locations

Unit #	Location
1	
2	
3	
4	
5	
6	
7	
8	

Unit #	Location
9	
10	
11	
12	
13	
14	
15	
16	

## Access codes

Table 16. Access codes

Code description	Code
Master code	
User code 1	
User code 2	
User code 3	
User code 4	
User code 5	
User code 6	
User code 7	
User code 8	
Duress code	

## Delays

Table 17. Delays

Delay	Time
Exit delay	
Entry delay	



Table 18. Simon XT system quick reference <sup>a</sup>

	Control panel	Remote touchpad	Keyfob	Telephone
Level 0: Subdisarm the system	Enter the master code while the system is disarmed.			①
Level 1: Disarm the system	<b>DISARM</b> , <access_code>.	Disarm		①
Level 2: Arm doors and windows	<b>DOORS+WINDOWS</b> , <access_code> (if required).	ARM Doors & Windows		②
Level 3: Arm motion sensors	<b>MOTIONS</b> , <access_code> (if required).	ARM Motion Sensors		③
Level 4: Arm doors, windows, motions	<b>DOORS+WINDOWS</b> , <access_code> (if required), <b>MOTIONS</b> .	ARM Doors & Windows  - ARM Motion Sensors	-	② - ③
Activate no delay	<b>DOORS+WINDOWS</b> , <b>DOORS+WINDOWS</b> . Appends <i>-No Delay</i> to arming level text.	ARM Doors & Windows  - ARM Doors & Windows		② - ②
Activate latchkey	<b>MOTIONS</b> , <access_code> (if required), <b>MOTIONS</b> .	ARM Motion Sensors  - ARM Motion Sensors	-  -	③ - ③
Activate panic alarm	Press <b>Fire</b> , <b>Emergency</b> , or <b>Police</b> twice within 3 sec. or hold it for 2 sec.	+  Hold both for 3 sec.	+  Hold both for 3 sec.	
Check system status	<b>STATUS</b>	SYSTEM STATUS		④
Toggle chime or special chime mode	Scroll to <i>Chime</i> or <i>Special Chime</i> , <b>Enter</b> , toggle <i>On/Off</i> , <b>Enter</b> .			
Bypass a sensor	<b>BYPASS</b> , <master_code>, scroll to the sensor, <b>BYPASS</b> .			
Time-activated lights on/off	Scroll to <i>Light Schedules</i> , <b>Enter</b> , toggle <i>On/Off</i> , <b>Enter</b> .			
Sensor-activated lights on/off	Scroll to <i>Sensor Lights</i> , <b>Enter</b> , toggle <i>On/Off</i> , <b>Enter</b> .			
Specific light on	Press *, <unit_num>.	- <unit_num>.		* - <unit_num>.
Specific light off	Press #, <unit_num>.	- <unit_num>.		# - <unit_num>.
All lights on	To turn on all lights controlled by lamp modules, press * twice. The panel displays <i>All Lights On</i> .	-		* - *
All lights off	To turn off all lights controlled by lamp modules, press # twice. The panel displays <i>All Lights Off</i> .	-		# - #

a. A minus sign (-) between buttons means *press one then the next*; a plus sign (+) between buttons means *press both simultaneously*.





programming ..... 23

## Q

quick exit ..... 12

quick reference chart ..... 47

## R

remote handheld touchpad ..... 17

restoration of power ..... 22

revision ..... 36

RF jam detected ..... 22

## S

safety terms and symbols ..... ix

security menu ..... 30

sensor failure ..... 22

sensor lights ..... 27

sensor locations ..... 44

sensor low battery ..... 22

sensor open ..... 22

sensor tampered ..... 22

sensors ..... 3

set clock ..... 26

silent exit ..... 11

siren options ..... 32

smoke and heat detector locations ..... 43

smoke detector ..... 2, 3

speaker volume ..... 33

special chime ..... 28

status ..... 15

status beep volume ..... 33

status beeps ..... 20

status icons ..... 8

system battery failure ..... 21

system download ..... 28

system features ..... 9

system limitations ..... 42

system menu ..... 24

system programming ..... 29

system status ..... 15

system tests ..... 28, 35

## T

testing ..... 37

*communication* ..... 39

*sensors* ..... 38

timers ..... 31

touchpads ..... 3, 17

trouble beeps ..... 21

## U

unbypass ..... 13

universal module ..... 2, 3

unlock button ..... 18

user codes ..... 24, 30

## V

voice chime ..... 14